



- "D" holes must remain OPEN after solder phase.
- When THT components aren't mounted, your holes must remain OPEN after solder phase.

- Heatsink must be cutted and drilled as BOM's indication
- Insulator must be cutted and drilled (See Heatsink)
- Stick the insulator on bottom side of Heatsink
- Put Heatsink on Top side of P.C.B.
- Insert 4 screws from bottom side of P.C.B. screwing them in the Heatsink

REVISION DATE		Description	Symbol	
		ASSEMBLY DRAWING	STSPIN32G4	
			Group	EVSPIN32G4
			TOLERANCE UNLESS NOTED	ISO
			UNIT=MM	SCALE : 1.5 : 1
			linear	Material
			0 <10 >10 <50 >200 LES.	REV. 1.0
Drawn	RIGO M.	date	21-Jan-2021	
Approved	date	accurate ±0.05	middle ±0.1	Treatment and surface finishing
			±0.15	±0.25
				±0.30