


Teseo-Suite

How to unlock advanced features





Introduction 2


- Teseo-Suite (v. 5.2.3 and later) is provided as a single executable file (no more Light and Pro versions)
- Certain advanced features are locked
- To unlock the advanced features, send an email requesting the activation key to st-teseo-suite-support@st.com





1st step: Request full version

- Go to the Help menu
- Select the Activate Teseo-Suite Pro
- Select Request full version





2nd step: Fill in the form

- Fill in the form with your company information (no gmail accounts permitted)
- Send the e-mail









3rd step: Enter the key 5

- Go to the Help menu
- Select the Activate Teseo-Suite Pro
- Select Activate full version



- 4 Enter the activation key
- Click the Activate button







Documents & related resources 6

All documents are available on: www.st.com

- Teseo II: Webpage
 - Datasheets for all products
- Teseo III: Webpage
 - Datasheets for all products
- Teseo Suite: Webpage
 - Datasheet
 - Install program



