










D open to provide VS different from VM



This drawing and the information herein are property of STMicroelectronics and are intended for evaluation purpose only



Board Title EVLDRIVE102BH

Sheet Title Current Sensing




Doc No

Date
Tuesday, November 26, 2024


Rev
1.0

Sheet
3 / 5


This drawing and the information herein are property of STMicroelectronics and are intended for evaluation purpose only



3.3V selector
default close 1-2: VDD from the STDRIVE102
close 2-3: VDD from the Nucleo Board



Solder bridge configuration for NUCLEO-G0 boards



Board Title EVLDRIVE102BH

Sheet Title Connectors

Doc No


Date
Tuesday, November 26, 2024

Rev
1.0


Sheet
4 / 5

This drawing and the information herein are property of STMicroelectronics and are intended for evaluation purpose only


Hall sensors/ Encoder connector




Phase voltage monitoring



NTC



Bus voltage monitoring



Board Title EVLDRIVE102BH

Sheet Title Sensing

Doc No

Date
Tuesday, November 26, 2024

Rev
1.0

Sheet
5 / 5

This drawing and the
information herein are
property of
STMicroelectronics
and are intended for
evaluation purpose only