

Schematic diagrams

Figure 1. STEVAL-QUADV01 circuit schematic (1 of 4)





Figure 2. STEVAL-QUADV01 circuit schematic (2 of 4)






EnPS03 VinPS03 VIN VinPS03 10uF C15 10uF VIN_AUX EnPS03 L3 Inductor 2.2uH _VoutPS03 Header 5 ΕN SW GND 101F AUX GND VinPS03 D0 D0 VOUT <u>D1</u> D1 GND 11 VoutAux D2 VOUT_AUX VinPS03 10uF ST1PS03AQTR C17 | GND VinPS03 GND

Figure 3. STEVAL-QUADV01 circuit schematic (3 of 4)





STEVAL-QUADV01 - Rev 2 page 2/3



IMPORTANT NOTICE - READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2024 STMicroelectronics – All rights reserved

STEVAL-QUADV01 - Rev 2 page 3/3